


In this sample we wish to map the [P1] physical key on a Zebra MC33 terminal.



Working with IBM5250 emulation:

First, we have to open *Settings - Key Programmer* to assign a non-used Telnet function to [P1] key. That is because we are using a Zebra device for the example; in other devices, find out the corresponding menu option to remap keys.

Select the button to remap [P1] and touch an Android function you don't use, to map to the button (in our example, PTT).




Open TellNext app, select a Profile and open *Test Menu - Keyboard* test at the right-top of the screen



Change the process you want to test to the corresponding 5250 Process.

Press the [P1] key and take note the scan code displayed (0123)



Exit TellNext in the terminal until get the Android Desktop screen.

The key mapping, in this case, is limited to the Internal Command association. We can assign any function defined by IBM for 5250 emulation.


See [5250 internal commands](#) here.

Edit, with VisualJsonEditor, the [_tnx_process.jcf](#) file associated with the 5250 emulation Process you want to use.



Goto Keyboard.SccToCmdMappings.Tn5250 and add a new value to the array. Set the scan code you get at Keyboard Test for the desired function.

Note: Usually the scan codes begin with "0" and internal commands with "1" or "2".



62 Object **Key_Custom_P1** - Remove

Label
The only purpose of the label is to describe what scancode corresponds to.
Key_Custom_P1

ScanCode
Scan code as a two bytes hexadecimal value. The low order byte being the virtual key code, and the high order
0123

InternalCommand
Associated 5250 function to send to the server.
105A

As we mention, we are limited to the already-implemented IBM functions for 5250 emulations. In our example, the Internal Command associated (105A) corresponds to the 5250_FORWTAB function.

Warning: if you assign an existing scancode, the function applied will be the one associated to the first register found in the list. For example, if we already have the 0123 scan code assigned to the 2031 internal command, the [P1] key will execute an ENTER instead of a FORWARD_TAB.

See the information about [5250 internal commands](#).

Validate, save and close the file

Push it to the device and open again TellNext in Android Terminal.

If we check again the association through *Keyboard test* menu, we can see the new function assigned.

So, if we open the Telnet login screen, we can test the FORWARD_TAB function pressing [P1] key.