

To assign a character string to one key you must modify the `_tnx_process.jcf` file.

Let's take an example to make the process more understandable:

The objective is assigning the "TST" string + TAB function to the P1 key in Honeywell EDA60K.

