

Latest recommended config:

\_tnx\_profile.jcf

```
"BluetoothSPP": {
  "On": true,
  "Filter": "RS507",
  "PIN": "",
  "UseDeviceMajor": false,
  "UnpairAll": false,
  "DiscoveryOn": false,
  "BarcodeType": "FNC3",
  "ShowUnpairBarcode": false,
  "ScannerType": 6,
  "TerminatorWait": 0,
  "Terminators": ""
},
```

\_tnx\_application.jcf

```
"Bluetooth": {
  "OnAtStart": true,
  "OffAtExit": true,
  "KeepPairingOnExit": false,
  "KeepPairingOnStartup": false
}
```

Tested successfully on:

Android Oreo (8.x)					
Manufacturer	Device	Android Version	Date	Tnx version	Recommended Config
	Notes				

Android Nougat (7.x) - <a href="#">No more tested on this version</a>					
Manufacturer	Device	Android Version	Date	Tnx version	Config deviation / Notes
Unitech	WD100	7.1.1	17/03/20	Emulator 1.0.13.513 BT Pairing 7.0.4.505 Vxt Engine 4.2.5.501 Vxt Calibrate 6.1.2.506	<code>"UnpairAll": false,</code> <code>"ScannerType": 6,</code>
	<ul style="list-style-type: none"> <li>• Build number SQ46W_P1_00AX_YBUTE_AU1616_404_R_0_190715_01</li> <li>• Scanner reconnected automatically</li> <li>• Voice projects <ul style="list-style-type: none"> <li>◦ "HeadsetType": 1 (in _vxt_configuration.jcf file)</li> <li>◦ Headset reconnected successfully</li> </ul> </li> </ul>				

## Recommendations:

- Use the Filter parameter as much as you can. It will be easier to establish the connection between devices.
- Every time TellNext is closed, the scanner battery must be removed and reinserted again when TellNext is opened again.