



## MAX SIZE REACHED

When the maximum size of the capture file is reached, the capture stops, and the following message is displayed:




CONTINUE: the recording will resume and the new limit size will be  $(\text{CurrentFileSize}/1024)$  [in Bytes] + ConfigSizeLimit [ in Ko, specified in the configuration parameter Network.Capture.SizeLimit]

STOP RECORDING: the capture will stop.



## EXISTING CAPTURE FILE

If the operator requests a capture and the maximum size of the file has already been reached, the user will be prompted:



CANCEL: the capture is not activated

CONTINUE: the capture is enabled



DELETE AND CONTINUE: the already existing TNST file will be deleted and a new TNST file will be created to record the new capture. In addition, the capture will be initiated and notified to the operator as above.



## PARAMETER FILE EMPTY

If the value of the parameter Network.Capture.File is empty

