

Recommended AudioMode parameter config for using the Silverback headset:



\_vxt\_configuration.jcf

```
"Microphone": {  
  ...  
  "Bluetooth": {  
    ...  
    "AudioMode": "MODE_NORMAL"  
  }  
},
```

Use MODE\_NORMAL.

If another AudioMode is used for this headset, the volume needs to be turned up to maximum to hear the beep.