

Latest recommended config:

\_tnx\_profile.jcf

```
"BluetoothSPP": {
  "On": true,
  "Filter": "RS507",
  "PIN": "",
  "UseDeviceMajor": false,
  "UnpairAll": false,
  "DiscoveryOn": false,
  "BarcodeType": "FNC3",
  "ShowUnpairBarcode": false,
  "ScannerType": 2,
  "TerminatorWait": 0,
  "Terminators": ""
},
```

## Tested successfully on:

Android Oreo (8.	Android Oreo (8.x)							
Manufacturer	Device	Android Version	Date	Tnx version	Recommended Config			
	Notes							
Zebra	TC51	8.1.0	24/07/19	Emulator 1.0.11.517 BT Pairing 7.0.3.550 Vxt Engine 4.2.3.501 Vxt Calibrate 6.1.2.501	"ScannerType": 2,			
	- The test is old, we recommend using Scanner Type 111 (not tested) - Sometimes it is needed to read the pairing barcode twice with ScannerType 6							

Android Nougat (7.x) – <u>No more tested on this version</u>						
Manufacturer	Device	Android Version	Date	Tnx version	Config deviation / Notes	



Zebra	Zebra	TC51	7.1.2	18/07/19	Emulator 1.0.11.512 BT Pairing 7.0.3.549	"ScannerType": 2		
		- Wait for the second beep when pairing scanner						

## Recommendations:

- Some devices are not available for testing, despite this, we recommend the use of Scanner Type 111
- Use the Filter parameter as much as you can. It will be easier to establish the connection between devices.

## Scanner Type 111:

- The use of ScannerType: 111 for Zebra devices requires the BT Pairing service at Android Accessibility menu option to be activated. In addition, it is convenient to use UnpairAll: false, to avoid having to scan multiple times to connect the scanner. UnPairAll: true could be more problemathic when you stablish the connection between the device and the scanner.
- Before using the scanner, please, scan the SPP mode and the Non-AutoReconnect barcodes:

SPP bar code



\*Nlono

